

◆ Handset lock :

Press and hold the "M" button (**about 8 seconds**) until the LED display switches to "S -" and then to "LOC." Release the button.

◆ Handset unlock:

Press and hold the "M" button (**about 8 seconds**) until the LED switches from "LOC" to the height display. Release the button.