

## Setting the upper & lower height limits

### ◆ Setting the upper & lower height limits;

#### **Setting the Upper-Limit position:**

Use the UP/DOWN buttons to move the base to the desired maximum-height position. Press the “M” button for one time and release, then press the “UP” button for one time and release. The LED display will show “S-”. Then press and hold the “M” button (about 2 seconds) until the LED display changes to “999”. The display will automatically return to the selected height. The new upper limit is now set.

#### **Setting the Lower-Limit position:**

Use the UP/DOWN buttons to move the base to the desired minimum-height position. Press the “M” button for one time and release, then press the “DOWN” button for one time and release. The LED display will show “S-”. Then press and hold the “M” button (about 2 seconds) until the LED display changes to “000”. The display will automatically return to the selected height. The new lower limit is now set.

#### **Removing the Upper/Lower Limit Positions:**

Press and hold the “M” button until the LED display flashes “S -” and then release it. Within 5 seconds, press the “M” button again and hold for 2 seconds. The LED display will change to “555” and then automatically return to the height display. The upper and lower limits are now removed.

A RESET procedure requires the desk base to full retract (beyond any lower limit set).