

## Changing the anti-collision sensitivity

### ◆ Changing the anti-collision sensitivity;

Press the DOWN button on the Handset until the base reaches its lowest position. Press and hold the DOWN button again until the LED display reads "RST".

Press and hold the "UP" button (about 5 seconds) while the LED flashes "RST" and then switches to either:

10.5 = 10 kg. pressure (most sensitive)

10.6 = 15 kg pressure (middle setting)

10.7 = 20 kg pressure (least sensitive)

Release the "UP" button . Press and hold the "UP" button again until the desired setting is reached. Once the chosen setting is displayed, release the button and wait about 5 seconds for the display to return to "RST".

Finish the **reset** process by pressing and holding the DOWN button until the desk lowers a little bit more, slightly rises and stops. Release the button. The new anti-collision sensitivity setting is saved and your desk is now ready to use.